



Home > Products > ProX Stands > Lighting Truss & Crankstands > 14 Ft Heavy-duty Lighting Crank Stand for Lifting Truss Line Array Speakers 220 lbs Capacity

SKU: XT-CRANK14FT-220

Permalink: <http://www.proxdir.com>[Search on Google](#)

14 Ft Heavy-duty Lighting Crank Stand for Lifting Truss Line Array Speakers 220 lbs Capacity

[Find A Dealer](#)

Product Images

[Download Product Images](#)

Our Products And You

[submit your story](#)

ProX XT-CRANK14FT-220 14 Ft Heavy-duty Lighting Crank Stand for Lifting Truss Line Array Speakers 220 lbs Capacity

Description

The ProX **XT-CRANK14FT-220** Truss Heavy Duty Crank Stands play a crucial role in the Truss Systems, providing a temporary mounting solution for DJ lighting at events of various sizes. These stands boast features like Integrated casters, individually adjustable leg braces, and nylon guided leg sliders, all **compatible with matching Stands, Trusses, and T-Adapters** (available separately). Crafted from robust all-metal components involving steel and aluminum, they eliminate the need for direct lifting and lowering of heavy loads.

With convenient portability, the ProX Truss Heavy Duty Crank Stand effortlessly folds for transportation. Its robust cranking mechanism ensures smooth operation, making it an ideal choice for live bands and mobile DJ setups, effectively avoiding the need for strenuous lifting and lowering tasks. Notably, this crank perfectly complements our [XT-TADAPTER-U](#); however, please note that this adapter is not included with the crank stand.

Prioritize safety by adhering to these guidelines. A qualified individual should thoroughly inspect all rigging hardware, stands, and equipment before each use, conducting periodic comprehensive assessments for wear, misuse, and overall adequacy. Additionally, adhere to manufacturer-recommended maintenance and follow all safety precautions and usage instructions outlined in the complete manual. Use the equipment at your own discretion and risk.

SAFETY INSTRUCTIONS

To avoid problems a competent person should inspect all rigging hardware, stands and equipment before each use and periodically do a major inspection for signs of wear, abuse, and general adequacy, as well as perform any manufacturer-recommended preventive maintenance on schedule. Observe all warnings and usage instructions in the full manual. Use at your own risk.

Basic Usage: Ensure that the stand is positioned on hard stable surface, in suitable location, on firm ground and clear of overhead obstacles. Stabilize legs before lifting the tower or any load. When outdoors, secure the tower with braces or cables, in case of wind.

Check the cable, it should not show damaged or flattened areas nor broken strands.

Using the Winch: For Lifting the tower, turn the winch handle clockwise. For lowering the tower, turn the winch handle counter-clockwise.

Safety Notes:

Loading on truss and stands should comply with rated weights.

Lock all the safety mechanisms (safety pins, knobs)

Loads must be centered & balanced on each lifting unit.

Safety chains must be installed on each item attached to the unit.

Leave a safety perimeter with a radius 5ft greater than the maximum height of the stands during lifting and lowering of loads.
During transport, close all the sections and lock the lifting carriage.
Do not attempt to move the stand when loaded or in the extended position.

Service Notes:

Servicing and repairs must be made by qualified persons.
Cable, pulleys, and telescopic masts must be inspected before each use. Any damaged cable must be replaced immediately.
An annual inspection by an authorized technician is suggested.

Features

- **Max Vert Load: 220 lbs.**
- **Base Diameter: 63" / 5.25FT**
- **Weight: 46 lbs.**

Shipping Dimensions & Weight

Box 1 of 1: 9.00"H x 11.00"W x 69.00"L - Shipping Weight: 63.00 lbs

Suggested Shipping Method: Parcel

UPC

741459147464

Our Products and You

Submit your
story

Commonly Asked Questions

+ Where can I buy one?

[submit a question](#)

Customer Testimonials

What did you think

Related Products



Set of (2) 17 in. Universal T-Adapter Brackets for F34/F33/F32 Triangle Square Truss Segments

SKU: XT-TADAPTER-U



4.92 Ft - 1.50 M F34 Square Truss Segment | 2 mm Wall

SKU: XT-SQ492



XT-CRANK22FT-400 Heavy Duty 22 Ft. High Truss Crank Up Lighting Stand 400 Lbs. Capacity Includes T-Adapter Truss Mount

SKU: XT-CRANK22FT-400



Universal 5ft Lighting Cross Bar w/Bolts
SKU: XT-LSTBAR-5FT



6 Way Square Truss Junction Block - Includes 2 Way 8 Half Conical Couplers
SKU: XT-JB6W-2W